

Cell Optimisation of Supercapacitors through the use of a Quasi-reference Electrode and Potentiostatic Analysis

Lewis Le Fevre

Richard Fields, Edurne Redondo, Rebecca Todd, Andrew J. Forsyth and Robert A. W. Dryfe

National Graphene Institute, University of Manchester, M13 9PL, Manchester, UK

Lewis.lefevre@postgrad.manchester.ac.uk

In this study, the authors demonstrate a new potentiostatic aging method for the electrochemical stable potential window (ESPW) of supercapacitors and thus the calculation of the optimal mass ratio for electrode-electrolyte pairings. For this purpose a novel quasi-reference electrode (QRE) was incorporated within CR2032 coin cell containment enabling three electrode potentiostatic aging measurements to be performed using organic electrolytes whilst outside of a glovebox. Monitoring of the final current during potentiostatic aging was used to determine the ESPW of each electrode. Calculation of the voltage optimised mass ratio for activated carbon electrodes in 1 M TEABF₄ ACN and PC electrolytes was achieved through attained knowledge of the ESPW and associated capacitance values[1]. The validity of the technique and use of the QRE is verified by full cell potentiostatic aging experiments on mass balanced and mass symmetric supercapacitors[2]. For both electrolytes the operating voltage and cycle lifetime of the device was improved significantly.

References

- [1] D. Weingarh, H. Noh, A. Foelske-Schmitz, A. Wokaun, R. Kötz, A reliable determination method of stability limits for electrochemical double layer capacitors, *Electrochim. Acta.* 103 (2013) 119–124.
- [2] S. Vaquero, J. Palma, M. Anderson, R. Marcilla, Mass-balancing of

electrodes as a strategy to widen the operating voltage window of carbon/carbon supercapacitors in neutral aqueous electrolytes, *Int J Electrochem Sci.* 8 (2013) 10293–10307.

Figures




Figure 1: **A)** Schematic showing the setup of incorporating the Ag wire QRE within the CR2032 coin cell. **B)** and **C)** Images showing the Ag wire QRE and its incorporation.




Figure 2: Cell capacitance retention with respect to time during cycling for mass symmetric ($m^+/m^- = 1$) and mass balanced ($m^+/m^- = 2.4$) cells up to different sequential cut off voltage ranging from 2.5 to 3 V for 1 M TEABF₄ in ACN.