



FIGURE 7. Examples of AFM examination of GO samples.

## CONTACT PERSON

Dr. Erik Khranovskyy, PhD <u>ceo@grafren.se</u> +46700895814 www.grafren.se REFERENCES

P. Bögild, The war on fake graphene, Nature 562, 502-503 (2018)
 ISO. Nanotechnologies-Vocabulary-Part 13: Graphene and Related Two-Dimensional (2D) Materials

10 g

www.iso.org/standard/64741.html (2017). [3] A. Kovtun et al. Benchmarking of graphene/based materials: real commercial products versus ideal graphene, 2D Materials, 6 025006 (2019).

(4) Patent Appl. No. 1950819-1 "Method for redistributing a flake material into at least two flake size fractions" (filed 28 June 2019). [5] C. Gómez-Navaro et al. Electronic transport properties of individual chemically reduced graphene oxide sheets, Nano letters 7(1) 3499 (2007).

2-10 layers

1 laye

FIGURE 8. Examples of weight yieald of the process

after 1 run for specific GO paste sample.

AFTER

RUN

ISO standard [2] 2,8±0,2 g

1.5±0.1 g

SUMMARY

- The innovative procedure for washing graphene oxide sludge and separation of flakes is suggested.
- The process allows separation of GO flakes of the thickness/size, required by the ISO Standard for Graphene and 2D Materials.
  The process can be run several times, aiming on fine separation of the
- The process can be run several times, aming on the separation of the flakes, potentially reaching 100% single flakes composition.
   Process is scalable and flexible, being potentially used by both GO
- Process is scalable and Texible, being potentially used by both GO manufacturers as well as GO users as a tool for quality assurance.
   Process is independent on the quality of incoming material and can be
- Process is independent on the quality of incoming material and can be potentially expanded for other 2D materials with quality issues.

